

FEATURES:

- True Colours of Real Image
- Player Select Various Beautiful Models
- Vertical Kit
- Flipper Arcade Machine Way + Vivid Video Image

Lots of International nude models from world wide 1 player shots the ball and reached score, there is a paradise of fantastic hot girls. Enjoy pinball game by real video image This will be the hottest adult game of the year. Higher score, hotter girl !!!

Control:

left push buttons

right push buttons









select	
stage	

set stage select mode

flipper button left shoot & shake button left

in the game

shoot & shake button right

flipper button right VIDEO TRUE COLOR IMAGE GAME BY PPER MACHINE GAME

SHOCKING

6 1995 COMAD INDUSTRY CO., LTD. ALL RIGHTS RESERVED

FEATURES

- Vertical kit
 Continuation
 Exciting models

TRUE IMAGE (F Grade)









Lots of International nude models from world wide

1 player shots the ball and reached score,
there is a paradise of fantastic hot girls.
Enjoy pinball game by real video image.
This will be the hottest adult game of the year.
Higher score, hotter girl !!!

■ PIN ASSIGNMENT ■

■ DIP SWITCH SETTINGS ■

SOLDERSIDE		COMPONENT SIDE	DIP SWITTCH 1			2	3	4	5	6	7	8
GROUND	1	GROUND		1 COIN 1 CREDIT		OFF						
GROUND	2	GROUND		1 COIN 2 CREDITS	ON	OFF	OFF					
+ 5V	3	+ 5V		1 COIN 1 CREDIT 2 COINS 3 CREDITS	OFF	ON	OFF					
+ 5V	4	+ 5V		2 COINS 1 CREDIT	ON	ON	OFF					
+ 34		T 3V	COIN SW 1	3 COINS 1 CREDIT		OFF	ON					
1077	5	1 1017	00111 011 1	4 COINS 1 CREDIT 2 COINS 1 CREDIT			ON					
+ 12V	6	+ 12V		3 COINS 2 CREDITS	OFF	ON	ON					
KEY	7 8	KEY		1 COIN 1 CREDIT 5 COINS 6 CREDITS	ON	ON	ON					
	9			1 COIN 1 CREDIT				OFF		OFF		
ann i rrnn ()		app Arrin()		1 COIN 2 CREDITS						OFF		
SPEAKER(-)	10	SPEAKER(+)	j.	1 COIN 1 CREDIT 2 COINS 3 CREDITS	1			OFF	ON	OFF		
	11			2 COINS 1 CREDIT					ON	OFF		
VIDEO GREEN	12	VIDEO RED	COIN SW 2	3 COINS 1 CREDIT				OFF	OFF	ON		
VIDEO SYNC	13	VIDEO BLUE		4 COINS 1 CREDIT						ON		
SERVICE SW	14	VIDEO GROUND		2 COINS 1 CREDIT 3 COINS 2 CREDITS				OFF	ON	ON		
	15			1 COIN 1 CREDIT 5 COINS 6 CREDITS				ON	ON	ON		
COIN SW 2	16	COIN SW 1		3							OFF	
	17	1P~4P START BUTTON		4								OFF
	18	1,	BALL COUNTS	5	-						OFF	ON
	19					-					LOIY	1011
	20	,	DIP S	SWITCH 2	1	2	3	4	5	6	7	8
	21		-	NORMAL	OFF	OFF						
SHOT & SHAKE	22	FLIPPER "	DIECIOLII TV	EASY	ON	OFF						
BUTTON. R		BUTTON. L	DIFFICULTY	DIFFICULT	OFF							
FLIPPER	23	SHOT & SHAKE		MORE DIFFICULT	ON	ON					-	_
BUTTON. R		BUTTON. L		200,000/ 800,000	<u> </u>		OFF				-	-
	24		EXTEND PLAYER	200,000		-	ON	OFF	-		-	
	25		1	100,000 / 500,000 NO		-	OFF ON	ON			-	-
	26			NORMAL -	-	-	OIV	OIV	OF.	₹	-	
GROUND	27	GROUND	HIT DIFFICULTY	DIFFICULT	+				ON			
GROUND	28	GROUND	DEMONSTRATION	YES							OFF	
,,	~	41.001.0	SOUND	NO							ON	